



Zanussi Electrolux Dishwasher Plate Eutron 401637 3390014



Product codes:

Reference: 401637

EAN13: -

UPC: -

Product description:

Zanussi Electrolux Dishwasher Plate Eutron 401637 3390014

Alpeninox 049910, 0L0045, 0L0261, 0L0541, 0L0705, 0L1412, 0L1811, 0L2583

Ascaso LZ.284

Atel 29LS003

Electrolux 049622, 049653, 049654, 049750, 049751, 049752, 049753, 049845, 049854, 049910, 0KE951, 0KE955, 0KU198, 0L0012, 0L0045, 0L0261, 0L02621, 0L0541, 0L0705, 0L1239, 0L1412, 0L1811, 0L2583, 29LS003, 452670170, 452670181

Epms 1430525

GEV 401637

Whirlpool 260705, 401637, 771985012994

Zanussi 049910, 0L0045, 0L0261, 0L0541, 0L0705, 0L1412, 0L1811, 0L2583, 401637

Product features:



Shop name

Application: Washing
Dishwasher Parts: Electronic Plate

Product short description:

Product gallery: